

This remote battery stud will allow you to establish a remote battery or ground connection at almost any location. **When adding multiple accessories and especially any solid-state accessories it is good idea to ground those accessories direct to the battery.** Because most antique vehicles are more than forty years old, the accumulation of dirt, oil, grease, and rust makes it difficult to establish a good ground thru the body or frame. **This Remote Battery Stud is rated at 200 amps.**



Install Instructions - Battery Power (Red Base)

- 1) Mount the Remote Battery Stud securely at the desired location.
- 2) Secure an 8-gauge wire directly from the battery (+) to the Remote Battery Stud. The diameter of the remote battery stud is (3/8").
- 3) Attach additional battery leads as needed. Be sure all circuits are fused.

Install Instructions – Battery Ground (Black Base)

- 1) Mount the Remote Battery Stud securely at the desired location.
- 2) Secure an 8-gauge wire directly from the battery (-) terminal to the Remote Battery Stud. The diameter of the remote battery stud is (3/8").
- 3) Add additional accessory grounds as needed.

Be sure all connections are tight when you are done. **DO NOT** put accessory battery “positive” wires and accessory ground wires onto the same remote stud! Use a separate Battery stud for each! Red for Battery (+), Black for Battery (--).

QUESTIONS -- Call FIFTH AVENUE ANTIQUE AUTO PARTS

Ph. 785-632-3450

E-mail – fifthave@oz-online.net

Website – fifthaveinternetgarage.com